

Water Meter Reading Worksheet

Recurring Work Order to Read Water Meters every 30 days
Please use site map provided to identify location of water meters.
Please use Water Meter Reading Tutorial if needed.

PROPERTY NAME: **Clark Manor**

Meter ID	Meter Number	Meter Type	Date	Time	Meter Reading
2	0075540648	Domestic			
3	0075747433	Landscape			

Meter Reading Completed By _____

When readings are completed please email this form to water@aelandscapedesign.com or fax to (909) 941-6876.

LEGEND

Building #



Water Meter



Backflow



Irrigation Controller



Fire Service



Domestic



Mixed



Reclaimed Water



Landscape



Fire



Other



Advanced Environmental Landscape
Design & Consulting, LLC

CSLB C-27 Lic#708716
PO Box 8296, Alta Loma, CA 91737
Phone: 909.980.8300 Fax: 909.941.6876
www.aelandscapedesign.com

SITE
Clark Manor
13032 Columbia Way
Downey, CA 90242
Prepared by Water Management
Dated 09/30/2015


NOTES:

QUICK WATER METER- TUTORIAL



- Flow Indicator (red sweep hand)**
Used when measuring low flow through the meter. The flow indicator measures in U.S. Gallons (0-9).
- Leak Detector (white triangle)**
If no water is being used inside or outside, this indicator should not be moving. If it is rotating, you may have a leak.
- Place Holder**
Indicated by [0]. The red sweep hand provides this information.
- Meter Register**
Every turn of the first black number measures 100 gallons; the second, 10 gallons.
Every turn of the last white number measures 1000 gallons.
- Meter Number**
17359133

How to Read Meter with Dial



4,567,970.7

Round this number down, this number will change once the dial makes a full turn

9,999,998.4

How to Read Meter without Dial

